





Level: 2nd Floor

Bundle: EXT-3

Bundle #1 of 3



- ☐ Row 1: 2-E18
- ☐ Row 2: 2-E17
- ☐ Row 4: Hold 1-00-12 2-E16
- ☐ Row 5: Extend 0-12 2-E15
- ☐ Row 6: Hold 1-04 2-E14
- ☐ Row 7: Extend 1-04 2-E13



Instructions to Driver



Level: 2nd Floor

Bundle: EXT-4

Bundle #2 of 3





- ☐ Row 1: 2-E23
- ☐ Row 2: 2-E22
- ☐ Row 4: Extend 9-13 2-E20
- ☐ Row 5: Extend 3-04 2-E19
- ☐ Row 6: Hold 2-01-13 2-E21

Instructions to Driver

Level: 2nd Floor

Bundle: INT-2

Bundle #3 of 3



- | | |
|--------------------------|--|
| ☐ | Row 1: 2-I15 |
| ☐ | Row 2: Extend 5-12 2-I18 |
| ☐ | Row 4: Hold 9-10 2-I20 |
| ☐ | Row 5: Hold 7-07 2-I19 |
| ☐ | Row 6: Extend 10-14 2-I28, 2-I26 |
| ☐ | Row 7: Extend 8-13 2-I14, 2-I13 |
| ☐ | Row 8: Extend 3-14 2-I21, 2-I22, 2-I23 |
| ☐ | Row 9: Extend 3-00 2-I27, 2-I16 |
| ☐ | Row 10: Hold 10-15 2-I29, 2-I25 |
| ☐ | Row 11: Extend 10-07 2-I24, 2-I17 |

Instructions to Driver