



Indicates left end of truss		Drawing is not to scale u.n.o.	Dashed walls indicate a non-bearing wall
Client:		By signing below, I agree that I have reviewed this layout and the attached truss drawings and found them to be in have deviated from the plans.	Disclaimer: This Truss Placement Diagram was not created by an engineer, but rather by the Truss Staff and is purely to be used as an installation guide and does not require a seal. Complete truss engineering and analysis can be found on the Truss Design Drawings which may be sealed by the Truss Designer.
Job Name:			
Job #:			
Location: SHOW LOW AZ			
		Signed: _____	
		Date: _____	