





Level: 1st Floor

Bundle: EXT-1

Bundle #1 of 3



- ☐ Row 1: 1-E6
- ☐ Row 2: 1-E5
- ☐ Row 4: Hold 1-00-12 1-E4
- ☐ Row 5: Extend 0-12 1-E3
- ☐ Row 6: Hold 1-04 1-E2
- ☐ Row 7: Extend 1-04 1-E1



Instructions to Driver



Level: 1st Floor

Bundle: EXT-2

Bundle #2 of 3



- ☐ Row 1: 1-E12
- ☐ Row 2: 1-E11
- ☐ Row 4: Extend 2-12 1-E8
- ☐ Row 5: Extend 1-05-04 1-E9, 1-E7
- ☐ Row 6: Hold 2-08-12 1-E10



Instructions to Driver



Level: 1st Floor

Bundle: INT-1

Bundle #3 of 3



- ☐ Row 1: 1-I2
- ☐ Row 2: Hold 5-08 1-I1
- ☐ Row 4: Hold 1-10-14 1-I4
- ☐ Row 5: Extend 1-00 1-I3
- ☐ Row 6: Hold 5-12 1-I8
- ☐ Row 7: Extend 0-08 1-I5, 1-I7, 1-I10
- ☐ Row 8: Hold 0-08 1-I6
- ☐ Row 9: Extend 8-00 1-I9, 1-I11
- ☐ Row 10: Hold 1-02-04 1-I12

Instructions to Driver