


Panel #EX66 Length: 12' 0" Height: 8' 1-1/8" First Stud Face @1' 3-1/4" (1' 4" o.c.) Diagonal: 14' 4-7/8"

IMPORTANT:

THE CUSTOMER WILL BE BUILDING IN WINTER AND IS ASKING THAT YOU DO NOT CUT THE SHEATHING OUT FOR THE WINDOW AND DOOR OPENINGS.

THEY WILL CUT THE SHEATHING ON SITE.

RICHARD



Top Plates: 2x8 DF #2 12' 0" Bottom Plates: 2x8 DF #2 12' 0"

 Studs: (9) 2x8 SPF #2 7' 8-5/8"


Components & Subcomponents	Start	End
Custom (2x4 Dn)	11' 5-1/2"	@ End
Exterior Sheathing: 7/16 OSB (8)	Start: Flush	End: Flush
Fastener: 8d	Spacing: 6" / 1' 0"	

Panel #EX65 Length: 15' 0-1/4" Height: 8' 1-1/8" First Stud Face @1' 3-1/4" (1' 4" o.c.) Diagonal: 17' 0-1/16"
IMPORTANT:

**THE CUSTOMER WILL BE BUILDING IN WINTER AND
IS ASKING THAT YOU DO NOT CUT THE SHEATHING
OUT FOR THE WINDOW AND DOOR OPENINGS.**

THEY WILL CUT THE SHEATHING ON SITE.

RICHARD



Top Plates: 2x8 DF #2 15' 0-1/4" Bottom Plates: 2x8 DF #2 15' 0-1/4"
Studs: (4) 2x8 SPF #2 7' 8-5/8"

Components & Subcomponents	Start	End
(1) 2x8 SPF #2	2' 2-1/4"	2' 3-3/4"
5S	3' 0-1/4"	3' 7-3/4"
(1) 2x8 SPF #2	4' 7-1/2"	4' 9"
Custom	5' 2-1/2"	5' 4"
W 025 HDR2 (6' 11-3/8")	5' 4"	12' 4"
(1) 2x8 SPF #2	14' 1-1/4"	14' 2-3/4"

Exterior Sheathing: 7/16 OSB (8)

Fastener: 8d

Start: Flush

End: Flush

Spacing: 6" / 1' 0"


Panel #EX64 Length: 16' 0" Height: 8' 1-1/8" First Stud Face @1' 5-1/4" (1' 4" o.c.) Diagonal: 17' 10-1/2"

IMPORTANT:

THE CUSTOMER WILL BE BUILDING IN WINTER AND
IS ASKING THAT YOU DO NOT CUT THE SHEATHING
OUT FOR THE WINDOW AND DOOR OPENINGS.

THEY WILL CUT THE SHEATHING ON SITE.

RICHARD



Top Plates: 2x8 DF #2 16' 0" Bottom Plates: 2x8 DF #2 16' 0"
Studs: (5) 2x8 SPF #2 7' 8-5/8"

Components & Subcomponents	Start	End
Custom (2x6 Dn)	@ Start	8-1/2"
(1) 2x8 SPF #2	1' 5-1/4"	1' 6-3/4"
W 024 HDR2 (6' 11-3/8")	6' 5"	13' 5"
Exterior Sheathing: 7/16 OSB (8)	Start: Flush	End: Flush
Fastener: 8d	Spacing: 6" / 1' 0"	


QR Pin

Panel #EX63 Length: 11' 4-3/4" Height: 8' 1-1/8" First Stud Face @2' 1-1/4" (1' 4" o.c.) Diagonal: 13' 10-7/8"
IMPORTANT:

**THE CUSTOMER WILL BE BUILDING IN WINTER AND
IS ASKING THAT YOU DO NOT CUT THE SHEATHING
OUT FOR THE WINDOW AND DOOR OPENINGS.**

THEY WILL CUT THE SHEATHING ON SITE.

RICHARD



Top Plates: 2x8 DF #2 11' 4-3/4" Bottom Plates: 2x8 DF #2 11' 4-3/4"
Studs: (2) 2x8 SPF #2 7' 8-5/8"

Components & Subcomponents	Start	End
Custom (2x8 Dn)	8-1/8"	1' 4-7/8"
(1) 2x8 SPF #2	2' 1-1/4"	2' 2-3/4"
W 023 HDR2 (6' 11-3/8")	2' 10-3/4"	9' 10-3/4"
(1) 2x8 SPF #2	10' 5-1/4"	10' 6-3/4"
Exterior Sheathing: 7/16 OSB (8)	Start: Flush	End: Fly 7-1/4"
Fastener: 8d	Spacing: 6" / 1' 0"	


Panel #EX62 Length: 16' 0" Height: 8' 1-1/8" First Stud Face @1' 4-3/4" (1' 4" o.c.) Diagonal: 17' 10-1/2"

IMPORTANT:

THE CUSTOMER WILL BE BUILDING IN WINTER AND
IS ASKING THAT YOU DO NOT CUT THE SHEATHING
OUT FOR THE WINDOW AND DOOR OPENINGS.

THEY WILL CUT THE SHEATHING ON SITE.

RICHARD



Top Plates: 2x8 DF #2 16' 0" Bottom Plates: 2x8 DF #2 16' 0"
Studs: (3) 2x8 SPF #2 7' 8-5/8"

Components & Subcomponents	Start	End
Custom (2x8 Dn)	@ Start	8-3/4"
(1) 2x8 SPF #2	1' 4-3/4"	1' 6-1/4"
(1) 2x8 SPF #2	2' 1-1/4"	2' 2-3/4"
Custom (2x8 Dn)	2' 10-1/8"	3' 6-7/8"
(1) 2x8 SPF #2	5' 0-1/4"	5' 1-3/4"
Custom (2x8 Dn)	5' 9-3/4"	6' 6-1/2"
(1) 2x8 SPF #2	7' 4"	7' 5-1/2"
W 022 HDR2 (6' 11-3/8")	8' 1-1/4"	15' 1-1/4"

Exterior Sheathing: 7/16 OSB (8)

Fastener: 8d

Start: Flush


End: Flush

Spacing: 6" / 1' 0"

IMPORTANT:

THEY WILL CUT THE SHEATHING ON SITE.

RICHARD



Top Plates: 2x8 DF #2 11' 4-3/4" Bottom Plates: 2x8 DF #2 11' 4-3/4"
Studs: (3) 2x8 SPF #2 7' 8-5/8"

Components & Subcomponents	Start	End
(1) 2x8 SPF #2	1' 2"	1' 3-1/2"
W 021 HDR2 (6' 11-3/8")	2' 2-1/2"	9' 2-1/2"
Exterior Sheathing: 7/16 OSB (8)	Start: Fly 7-1/4"	End: Flush
Fastener: 8d	Spacing: 6" / 1' 0"	

QR Pin


Panel #EX68 Length: 12' 0" Height: 8' 1-1/8" First Stud Face @1' 3-1/4" (1' 4" o.c.) Diagonal: 14' 4-7/8"

IMPORTANT:

THE CUSTOMER WILL BE BUILDING IN WINTER AND IS ASKING THAT YOU DO NOT CUT THE SHEATHING OUT FOR THE WINDOW AND DOOR OPENINGS.

THEY WILL CUT THE SHEATHING ON SITE.

RICHARD



Top Plates: 2x8 DF #2 12' 0" Bottom Plates: 2x8 DF #2 12' 0"

Studs: (9) 2x8 SPF #2 7' 8-5/8"


Components & Subcomponents	Start	End
Custom (2x6 Dn)	11' 3-1/2"	@ End
Exterior Sheathing: 7/16 OSB (8)	Start: Flush	End: Flush
Fastener: 8d	Spacing: 6" / 1' 0"	

Panel #EX67 Length: 11' 6-1/4" Height: 8' 1-1/8" First Stud Face @1' 3-1/4" (1' 4" o.c.) Diagonal: 14' 0-1/8"
IMPORTANT:

**THE CUSTOMER WILL BE BUILDING IN WINTER AND
IS ASKING THAT YOU DO NOT CUT THE SHEATHING
OUT FOR THE WINDOW AND DOOR OPENINGS.**

THEY WILL CUT THE SHEATHING ON SITE.

RICHARD



Top Plates: 2x8 DF #2 11' 6-1/4" Bottom Plates: 2x8 DF #2 11' 6-1/4"
Studs: (8) 2x8 SPF #2 7' 8-5/8"

Components & Subcomponents	Start	End
Custom	@ Start	3"
5S	3' 10-1/2"	4' 6"
Exterior Sheathing: 7/16 OSB (8)	Start: Flush	End: Flush
Fastener: 8d	Spacing: 6" / 1' 0"	